

HANDY HITCH

INSTRUCTIONS



1 Place the 1" x 2" reflector tape on the center of your tailgate or the bottom center of your back window. (Accuracy is important.)



2 Place the Handy Hitch on the trailer's tongue.



3 *Turn the stop plate so it faces your towing vehicle's ball and secure into place.



4 (SAMPLE of how stop plate should look when turned.)



5 Take the antenna and measure the height of the towing vehicle's ball by placing the tip of the antenna **gently** onto the ground and finding the distance to the **center** of the ball.



6 Take antenna and place tip **gently** on the ground in front of the trailer, raise or lower the trailer to get the stop plate to align with your measurement on the antenna.



7 Slide the outstretched antenna onto the bolt at the top of the Handy Hitch. Make sure the antenna and the stop plate line up parallel with the **center** of the tongue.



8 By looking over your shoulder or in your rearview mirror, **slowly** back up the towing vehicle, keeping the reflector tape and the antenna directly aligned.



9 The moment you see the antenna move, **STOP, set the parking brake** and put your vehicle in park. You should now be ready to hook up.



10 Remove the Handy Hitch from the ball and store under your seat for future use. Lower the trailer onto your vehicle. **SEE HOW EASY IT IS!**

*If trying to hitch a trailer from an angle, the stop plate can be adjusted in any position so that it will accurately line up with the towing vehicle.

You can adjust the stop plate forward or backwards for your own personal reaction time.

WARNING: Handy Hitch is not responsible for any damages.

Included: Handy Hitch, Antenna, Reflector Tape
Patent Pending. Made in the U.S.A.